# Hovo 600 Series Quick Start Guide

\*\*\* This product is not intended to replace traditional AC power vacuum cleaner. \*\*\*

# **Step 1. Unit And Accessories Check**

Refer to Package Contents (Page 3 of User Manual)

### **Step 2. Install Battery**

Battery is pre-installed in the battery compartment. Refer to page 4 of User Manual for battery compartment location and page 16.

Please remove the battery if you will not use the vacuum for a long period of time. If the vacuum encounters any unknown error, you can reset system by removing battery for 10 minutes, and then re-install the battery.

#### **Step 3. Charge Battery**

Turn on power switch on the side of vacuum and plug the AC adapter to the manual charging port of your vacuum.

Recharge battery manually for 4 hours before you use it for the first time.

Refer to Battery Charging Method section of User Manual (page 8).

Reminder – Power switch must be turned on before battery can be recharged properly.

#### **Step 4. Start Cleaning**

Turn on the power switch on the side of your vacuum, then press CLEAN button to start cleaning. Refer to Product Operations section on page 9 of User Manual.

# Reminder:

- Do not put virtual blocker or remote control next to charging station. Otherwise, the vacuum can not locate the charging station and do docking correctly because of interference.
- Remove debris & hairs from brushes and wheels if they are not spinning freely.
- Always turn the power switch off if the unit is not on charging station, or when it finishes cleaning, or when you transport it to preserve battery power.

### If you have question or issue on the product, DO NOT return it to the store. Please contact technical support first with live chat at: www.metapo.com There is more product information on FAQ web page: http://cleanmate.metapo.com



You can purchase accessories at www.amazon.com or http://store.cleanmateus.com/